



PRA REDUCING ADAPTER

Part No.	Pipe Size		Dimensions		
	P-PT, NPT	P ₁ -PT, NPT	A	E	F
PRA-04-02	1/4	1/8	31	5	3/4
PRA-06-04	3/8	1/4	38	7	7/8
PRA-08-04	1/2	1/4	44	7	1-1/16
PRA-08-06	1/2	3/8	44	9.5	1-1/16
PRA-12-06	3/4	3/8	46	9.5	1-1/4
PRA-12-08	3/4	1/2	50	12	1-1/4
PRA-16-08	1	1/2	57	12	1-5/8
PRA-16-12	1	3/4	57	15	1-5/8