



PRC REDUCING COUPLING

Part No.	Pipe Size		Dimensions		
	P-PT, NPT	P ₁ -PT, NPT	A	E	F
PRC-04-02	1/4	1/8	25	8	3/4
PRC-06-04	3/8	1/4	35	11	7/8
PRC-08-04	1/2	1/4	38	11	1-1/16
PRC-08-06	1/2	3/8	38	15	1-1/16
PRC-12-06	3/4	3/8	52	15	1-1/4
PRC-12-08	3/4	1/2	52	18	1-1/4
PRC-16-08	1	1/2	55	18	1-5/8
PRC-16-12	1	3/4	57	22	1-5/8